


Smart Video Doorbell Kit



Quick Operation Manual





Product Instruction

Unpacking inspection (picture and text comparison) Core component list

1. Indoor host (including power adapter)
2. Doorbell (pre-installed with 2*18650 batteries)
3. Installation accessories package (including 3M glue, screw set, etc.) Please fully charge the doorbell before installation

Charging status prompt:  Blue indicator light flashes → Charging
 Blue indicator light is on → Fully charged

It is recommended to charge for the first time for ≥6 hours




Product Application

The indoor host and doorbell are paired at the factory and can be used immediately after power on (supports up to 4 channels). If you need to add a doorbell or camera, please refer to the FAQ3 (page 6) operation guide.

(1) Power on

Connect the indoor host to the power supply (Figure 1), and turn the ON/OFF button on the side of the host to the ON position;

Turn on the doorbell or battery camera: Turn the ON/OFF button on the back of the doorbell to ON. After the indicator light comes on, the indoor host will automatically display the doorbell screen.



(2) Host network configuration mode

After the host is powered on, about 10 seconds later, the host will emit a continuous "beep beep" prompt sound, indicating that it is waiting for network configuration;

If there is no prompt sound: Use the reset needle to press and hold the reset button on the back for 5 seconds until you hear the reset success prompt sound.

(3) Connect to WiFi







As shown below: Press the WiFi setup button on the host, select the 2.4GHz WiFi network (5GHz is not supported), enter the WiFi password, and confirm the connection.

Tip: If the connection fails, please check whether the password is correct or restart the router.



Note: The Shift key can switch between uppercase and lowercase input.

Indoor host function introduction:

Area	Name	Function	Operation Tips
Screen display area	CH1~CH4	Default devices (such as doorbells)	Display real-time image
	Play	Click to play live video	Click Full Screen Mode again
	Add	Add New Device	Click on the QR code and scan it for pairing
Operation button area	Mute 	Turn mute function on/off	Mute can be turned on or off
	Arrow 	Navigation/Switch/Full Screen model Use up and down keys to set volume	Multiple devices, full screen mode, left and right arrow keys to switch viewing devices
	Confirm 	Short press: confirm Long press: Delete device	Deletion requires confirmation to prevent misoperation
	Back 	Return to the previous level /refresh the screen	Return to previous level /Refresh the screen
	WiFi 	Enter network settings	Switch WiFi or reconfigure the network
	Intercom 	Start two-way audio	When on a call, press and hold

(4) Remote access the doorbell kit

1. SriHome App Installation

Method 1: Search for “SriHome” on Google Play or iOS App Store.

Method 2: Scan the QR code to download “SriHome” App.



2. Registration & Login on SriHome App


3. Add device to SriHome APP

Please follow the instructions of the SriHome APP to add the device.


(The device ID is on the label of the host)




3-1




3-2



3-3



3-5



3-6

- 1 Channel 1
- 2 Channel 2
- 3 Channel 3
- 4 Channel 4

Windows ●
Green means online

Windows ●
Red means offline

Introduction for monitoring interface:

- | | | | |
|-------------------|------------------|---------------------|------------------------|
| 1. ☰ App Settings | 5. ⚙ Settings | 9. 📄 Local record | 13. 🗣 Intercom |
| 2. 📄 Scan code | 6. 🔍 Full screen | 10. 📷 Screenshots | 14. 🎞 Playback |
| 3. 📄 Split Screen | 7. SD Resolution | 11. 🔊 Speaker | 15. ☀ Light switch |
| 4. + Add | 8. ⬆ Up & down | 12. 🔋 Battery level | 16. 🌞 Lighting Control |


FAQ

FAQ1: Doorbell Installation

Two installation methods: Punch-free adhesive (recommended)/screw fixing. The indoor unit is recommended to be installed within 10 meters from the doorbell.


1. Four-step adhesive installation method: (recommended)

- (1) Film tearing: Remove the 3M adhesive protective film on the back of the wall mount.
- (2) Stick to the wall: Choose a smooth and clean wall and press hard for 10 seconds
- (3) Positioning: Keep the horizontal line and ensure that the wall mount is attached properly
- (4) Fasten: Align the top slot of the doorbell with the wall mount and press down until you hear a "click" sound.



2. Screw installation steps:


- (1) Drilling: Use the wall-mounted parts to mark the hole positions, drill holes with an electric hammer, and insert expansion tubes
- (2) Fixing: Tighten the wall-mounted parts with screws
- (3) Hanging the doorbell: Align the slots and press down to tighten (you can hear a "click" sound)



(Note: Do not install the doorbell on metal materials to avoid affecting the signal)

FAQ2: How to disassemble the doorbell?

(1) Use a screwdriver to loosen the fixing screws at the bottom (no need to remove it completely); (2) Hold the doorbell body and push it upward along the wall; (3) When the doorbell is free from the buckle, you can remove the device.



FAQ3: How to pair the indoor host with the doorbell

Note: The device is paired at the factory and is plug-and-play

Pairing steps (supports pairing up to 4 devices)


(1) Select a channel on the host (such as CH1-4) → Select "Add" and click OK to display the QR code.



(2) Press and hold the doorbell reset button for 5 seconds (you will hear a beep)

(3) Align the doorbell to the QR code (20-30cm) → "beep" means success

Note: Make sure the device is fully charged. If pairing fails, repeat steps 2-3 or adjust the distance/angle of the device.



Delete the doorbell step

(1) Select the channel to be deleted (e.g. CH1)

(2) Press and hold the OK button for more than 6 seconds, and the screen will change from "Play" to "Add"

(3) Done! Now you can pair a new doorbell.


(Optional configuration)

FAQ4: Share the smart doorbell to other user


The device supports multi-user viewing. Download SriHome App to register an account, and then the administrator can share permissions to watch.

1. Administrator operation: Administrator logs in to SriHome App, click Settings button->Visitor Management->Add->Select operator/visitor->Scan QR code New user App ID QR code (FAQ4-5)->Remarks name->Next step is completed (FAQ4-1~FAQ4-3)


2. Authorized users: Return to the APP monitoring interface and scroll down to refresh to view the monitoring.(FAQ4-6)



FAQ4-1




FAQ4-2



FAQ4-3


How to find the user APP ID in the mobile app?



FAQ4-4



FAQ4-5




FAQ4-6


FAQ5: Alarm and motion detection settings

1. Alarm settings (receive APP notifications)


- (1) Enable the mobile phone APP notification permission: Enter the mobile phone [Settings] - [Application Management/Permission Management] → find SriHome APP - enable the "Allow Notification" permission (the path varies for different mobile phones)
- (2) Enable alarm notification in APP: Open SriHome APP → Enter camera settings → Find the "Alarm Notification" option and turn on the switch.



FAQ5-1



FAQ5-2



FAQ5-3

2. Low battery alarm

Low battery alarm: APP Settings → Turn on "Low Battery Reminder" → When the camera battery is below the threshold, the APP will push a notification

3. PIR Settings

Human Inductor: After turning it on, you can adjust the detection frequency (15~180 seconds). The larger the value, the longer the detection interval.

PIR Schedule(Custom alarm): You can set the PIR alarm to be activated during a specific time period (10pm to 6am). During non-set time periods, the PIR will not trigger an alarm (suitable for shutting down during the day and enabling at night)

Other FAQ

Question 1: How to set the language of the indoor host?

1. Open SriHome App → Enter [Settings] → [System Settings] → [Language Settings].
2. Select the desired language (such as Chinese, English, etc.) → Click [OK] to save.

Question 2: Why is there no network prompt tone for the doorbell?

1. **Reset the doorbell:** Use a thin needle to press the reset button on the back of the doorbell for 5-10 seconds until you hear a "ding" prompt sound.
2. **Check the battery:** If there is still no prompt sound, the battery may be too low. It is recommended to charge for more than 6 hours before trying again.

Question 3: Why can't other brands of doorbells be added to the indoor host?

The indoor host only supports SriHome protocol devices (such as FA05 series) and does not support third-party doorbells.

Question 4: What should I do if the host goes offline after changing Wi-Fi?

1. **Reset the host:** Use the reset pin to press and hold the reset button on the back of the host for 5-10 seconds until you hear a "ding" prompt tone.
2. **Reconnect to Wi-Fi:** Wait for the host to emit a "ding ding" prompt tone → Enter SriHome App → Re-pair Wi-Fi.

Question 5: What should I do if the APP prompts "Indoor host is offline"?

1. Check the Wi-Fi signal

(1) Make sure the router is working properly and other devices can connect to the Internet normally.

(2) Check the host signal strength in the APP (if it is less than 2 bars, you need to optimize the position).

2. **Adjust the host position:** Move the host closer to the router(recommended distance <15 meters, reduce obstacles)If the signal is weak, consider using a Wi-Fi signal amplifier.

3. **Restart the device:** unplug the host power, wait 1 minute and plug it back in.